



## PRODUCT SPECIFICATION

QuietOn Dental package

Active Noise Cancelling earplugs

Product title	QuietOn earplugs
Technology used	Active noise cancellation technology and passive acoustic attenuation to reduce noise. Active noise cancelling technology is able to reduce low and high frequency sounds which traditional passive earplugs are not able to reduce.
Application / Indented use	QuietOn earplugs are used in ears to protect hearing by reducing noise.
Customs commodity code	85183095
Dimensions and weight of an earplug	22mm x 19mm x 16mm, 4g
Dimensions and weight of a charging case	59mm x 22mm x 30mm, 28g
Dimensions and weight of the complete package	110mm x 110mm x 55 mm, 153g
Battery	CoinPower "CP1254 A2" Lithium-Ion 50 mAh, (~300 Wh/l), integrated
Charging interface	Micro USB
Product's material composition	Plastic (polyamide and polycarbonate), silicone, polyurethane rubber and stainless steel
Preferential origin	EE/EU
Certifications	CE, FCC + Compliance with UL/CSA/IEC/EN 60065-1, EN-352-2 and EN-352-5 Hearing protection certificate, IP54
Patented technology	Patent covers active noise cancelling earplugs which fit in ear anatomy. FI126466 (Finland), 10171904 (USA)
Package Contents	<ul style="list-style-type: none"> <li>• One pair of QuietOn earplugs (R&amp;L) with Comply memory foam tips (size M)</li> <li>• Charging case with magnetic locking mechanism</li> <li>• Micro USB cable. A charger is not included in the package.</li> <li>• 8 pairs of silicone tips: 4 pairs blue (M) and 4 pairs green (S)</li> <li>• Retention cord and User manual</li> </ul>
EAN product code	6430064240274
Address of QuietOn HQ	Hakamaantie 18, 90440 Kempele, Finland
Address of QuietOn warehouse	Hakamaantie 18, 90440 Kempele, Finland
Delivery terms	EXW Kempele, Finland